Quad Dock

USER'S GUIDE

dreamGEAR's Quad Dock for the Wii, charges 4 separate Wii remotes or Rechargeable Battery Packs simultaneously. It has a built-in LED light which indicates when it has finished charging. dreamGEAR's Quad Dock saves you time and money and keeps you gaming!

for Wii™

dreamGEAR®
www.dreamgear.net

Contents:

1 - Quad Dock
4 - Rechargeable Battery Packs
1 - Power Pass-through cable

Getting Started

1) Make sure that the Wii console is turned off.
2) Plug the Wii DC plug into the Quad Dock power adapter input.
3) Insert the Quad Dock DC plug into the Wii DC plug input.
4) Plug the secondary Wii DC plug into the Wii DC input connector.
5) Turn on the Wii and start gaming!

USING THE Wii REMOTE WITH THE QUAD DOCK

1) Insert a dreamGEAR Rechargeable Battery Pack into a Wii Remote. Insert the Wii Remote with Rechargeable Battery Pack into the Quad Dock and make contact with the charging terminal. The LED will light up red indicating the charge cycle has begun. When the charge cycle is complete, the LED will light up blue.

2) To release the Wii Remote, simply lift and remove the Wii Remote from the Quad Dock.

CHARGING THE DREAMGEAR RECHARGEABLE BATTERY USING THE QUAD DOCK

1) Insert a dreamGEAR Rechargeable Battery Pack into the Quad Dock and make contact with the charging terminal. The LED will light up red indicating the charge cycle has begun. When the charge cycle is complete, the LED will light up blue.

2) To release the dreamGEAR Rechargeable Battery Pack, simply lift and remove it from the Quad Dock.

Troubleshooting

Problem: My controller isn't charging.

Solution: 1) Make sure the power source on the Quad Dock is plugged in properly and securely. 2) Make sure the Wii Remote with the Rechargeable Battery Pack is making proper contact with the charging terminals on the Quad Dock. Make sure the Quad Dock is free of dirt and debris. Make sure that none of the contacts on BOTH the controller and the Quad Dock are not damaged or compromised.

NOTE: Be sure and keep your Wii Remotes and Quad Dock clean. Dirt and debris harm the battery contacts. Use a dry cloth to clean. DO NOT use water or any chemicals to clean.

dreamGEAR®
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net